

Autostart 700 (model numbers AS3/E...)

mi5316
revision C, 31st January 2011
catalogue section 75




Engine/Generator Controller Installation Reference Sheet


Front View

4 position operating mode keyswitch:-
Off/reset
Lamp Test
Auto
Test (Manual)


7 status/fault LEDs



Rear View Settings and Connection




Top View and Settings




Before Nov 2010	After Nov 2010	Switch settings: (ON = up, OFF = down)
SW1	SW1+2	ON 12 V DC operation OFF 24 V DC operation
SW2	SW3+4	ON AC alternator speed sensing OFF Magnetic pickup speed sensing
SW3a	SW5	ON Battery charger fail warning OFF Charge alternator fail warning
SW3b	SW6	ON Load relay enabled in Test mode OFF Load relay disabled in Test mode

- | | |
|--------------------------------------|---------------------------------|
| 1 Battery -ve DC supply | 14 L Generator AC 50/60Hz |
| 2 Charge Fail input | 15 N 300 VAC max. |
| 3 Battery +ve DC supply | 16 Lamp test input/output |
| 4 - No connection - | 17 0 - 1 mA tachometer +ve |
| 5 Magnetic pickup input | 18 stop start |
| 6 Auto mode output: +ve, 250mA max. | 19 -ve |
| 7 Crank relay output: +ve, 16A max. | 20 High Engine Temp. input |
| 8 +ve DC (feed for relays) | 21 Interlock (plant fail) input |
| 9 Fuel relay output: +ve, 16A max. | 22 Low Oil Pressure input |
| 10 Alarm relay output: +ve, 16A max. | 23 Mains fail input |
| 11 NO | |
| 12 CO | |
| 13 NC | |
- Load relay output (volt free)

Panel Installation



Typical Connection (Automatic Mains Fail Application)



Electrical Connection

Electrical connection to the Autostart 700 is via individual 1/4 inch blade terminals. All connections should be made with Autostart switched off and the wiring isolated from the DC/AC supply:-

Pin Function

- 1 Negative DC power supply**
3 Positive DC power supply

Before connection of these terminals, ensure the supply voltage selector switch is correctly set for 12 or 24V DC (see Rear View Settings and Connection diagram). Failure to ensure correct settings may result in permanent circuit damage.

The AS700 has an internal, self-recharging Ni-Cd battery that protects against DC supply brown-outs during engine cranking. The internal battery charge is maintained as long as pins 1 and 3 are connected to the DC supply. Note: the internal battery means that Autostart cannot be reset or powered down by removing the DC power connections.

Use a 5 Amp anti-surge fuse in the positive DC power line (pin 3).

- 2 Charge fail input**

This may be activated by external connection to negative DC. Pin 2 may therefore be connected to a charge alternator WL terminal (Autostart provides the necessary excitation current), or to the 'charge fail' output of a Murphy BC700 series charger, or direct to negative DC via relay contacts which close on fault.

A rear switch (see Rear View Settings and Connection diagram) allows the Charge Fail LED to be configured for either mains charger mode (LED always active) or charge alternator mode (LED overridden before engine startup)

- 5 Magnetic pickup**

This terminal allows optional use of a magnetic pickup engine speed sensing. Magnetic pickup speed sensing must be enabled using a rear facia switch (see Rear View Settings and Connection diagram). Connect one terminal of the pickup to pin 5, the other terminal to pin 1 or battery negative. The interconnection must use a two core and screen cable, with the screen earthed at one end only.

If a magnetic pickup is not used, leave pin 5 open circuit.

- 6 Auto mode output**

Pin 6 gives a positive DC output (250mA max.) while the unit is switched to Auto mode.

- 8 Positive DC (feed for relays)**

Pin 8 is the common positive DC feed for the Crank, Fuel and Alarm outputs (pins 7, 9 and 10).

- 7 Crank output**

- 9 Fuel output**

Pins 7 and 9 give positive DC outputs (max. rating 16 Amps) for the control of engine fuel and starter motor circuits. Murphy recommend the connection of slave relays with suppressed coils between each output and the fuel/starter motor solenoid coils.

- 10 Alarm output**

Pin 10 gives a positive DC output (maximum rating 5 Amps) when Autostart has detected a fault and has shutdown the engine.

- 11 Load relay: normally open contact**

- 12 Load relay: change-over contact**

- 13 Load relay: normally closed contact**

The load relay is a volt-free set of SPCO relay contacts, used for the control of the generator contactor. The relay activates immediately after a generator start, provided that the generator is running within normal frequency, voltage and oil pressure limits. Once the 'mains fail' input de-activates, the load relay will remain energised (keeping the generator on load) until the 'changeback' timer has expired.

- 14 Generator AC Live**
15 Generator AC Neutral



Autostart uses these terminals to sense AC generator voltage. These terminals can also be configured to sense AC generator (alternator) frequency, which is proportional to engine speed – see Rear View Settings and Connection diagram. Voltage and frequency/speed information are needed for the correct operation of the crank release, load relay and overspeed trip.

A 1 Amp anti-surge fuse should be connected in series with the generator live terminal (pin 14).

- 16 Lamp Test input/output**

Switch S5 on the top facia sets the DC polarity of this input/output. When used as an input, this pin may be connected to the correct polarity supply rail, causing all LEDs to light. As an output, this pin gives the selected polarity signal when the Autostart is switched to LAMP TEST.

WARNING: incorrect polarity switch setting and connection will result in internal shorting and damage to Autostart and panel wiring.

- 17 RPM Meter/calibration output**

This output, with the rear facia multi-turn potentiometer, is used to calibrate the Autostart's speed sensing circuit – this is necessary for the correct operation of the crank release, load switching and overspeed trip. After correct calibration, the output may also be used to drive a suitably scaled engine tachometer.

With the engine running normally and Autostart correctly calibrated, this terminal should give a 0.75mA output into a 75 Ohm meter.

- 18 Manual Stop**
19 Manual Start

These terminals may be wired as above, providing operator controlled starting and stopping of the engine when the Autostart is in test/manual mode. Alternatively, hard-wire pins 18 and 19 to battery negative to give an immediate engine start on switching to test mode.

- 20 High Engine Temperature (HET) switch input**

- 22 Low Oil Pressure (LOP) switch input**

These inputs are dedicated for use with low oil pressure (LOP) and high engine temperature (HET) fault switches. Top facia switches S2, S3 and S4 allow the inputs to be configured for fault switches which open or close on fault, with wiring to either positive or negative DC.

Each fault switch is wired between the input and the appropriate DC rail. An 'active' input results in the automatic, immediate shutdown of the engine, and the lighting of the appropriate front facia LED.

- 23 Mains fail input**

Use this input to initiate an automatic engine start. Pin 23 must be switched to battery positive when the generator is required to be on standby, and made open circuit to initiate an automatic start.

Further information: -

Document Ref.	Description
ms5893	AS700 sales bulletin and specification



FRANK W MURPHY LTD.

Church Road, Laverstock, Salisbury, SP1 1GZ, United Kingdom

tel: +44 [0]1722 410055 fax: +44 [0]1722 410088

email: sales@fwmurphy.co.uk web: www.fwmurphy.co.uk



USA-ISO 9001:2008 FM 28221
UK-ISO 9001:2008 FM 29422
Registered Facilities

